

Fastime 30 instructions



Main Mode Navigation:

Press and hold **B** to cycle through the modes:

- Time/Calendar (Home Screen)
- Referee Match Timer
- Stopwatch

Sub-Mode Navigation:

- Step and Alarm mode: On the Calendar Screen, press and hold **C** to enter the Alarm mode. Press **B** to display step counter and timing.

Using the Referee Match Timer:

In Referee mode, the watch features a dual-timer layout. The main countdown timer tracks active play while an auxiliary timer tracks added injury time/extra time.

Setting Match Parameters (Pre-Game)

Navigate to the Referee Mode by pressing and holding **B**.

Press and hold **A** for 2-3 seconds until the location digits flash.

Press **B** to cycle through countdown timers, period, and break times..

Press **D** to increase the period duration (e.g. 45 minutes for standard matches). Press **C** to decrease the duration. Press and hold for quick digit change.

Press **A** to save and lock your settings.

During The Match:

Start the match: In Referee Mode press and hold **D** at the opening whistle. Both the main countdown timer and total elapsed time timer will begin.

Pause for injury/stoppage: Press and hold **D** during an incident. The main match countdown will freeze, but the background cumulative timer continue running to automatically calculate added time.

Resume play: Press and hold **D** when play restarts. The match clock resumes (thereby adding your extra time). The stoppage time is shown in the bottom line.

Start next period: When play resumes for the second period, or half, at the whistle press and hold **D** to start the top timer.

Reset after the match: Press and hold **C** to reset the timer.

Email: info@astopwatch.co.uk

Call: +44(0)7483 134 796

FASTIME

Fastime 30 instructions

Stopwatch Mode:

Press and hold **B** to cycle through the modes:

Press **D** to start timing.

Press **C** to record a lap time. Lap is shown in the upper row, Split is shown in the middle row (NB: in minutes, not seconds) and the bottom row show the cumulative running time.

When **C** is pressed the digits will pause for 6 seconds but the stopwatch will continue to run.

Press **D** to stop



Memory Recall:

Press **B** to enter memory recall and view the lap time and split time. Memory can be recalled anytime.

Press **D** to cycle through the data or press **C** to view the data in reverse order.

Press **B** to return to current running time or stopped stopwatch.

Clearing the memory:

To clear the memory, press all **4** buttons at once, NB this will reset the watch completely.

Turn off the display:

You can conserve your battery by turning off the display.

In the Calendar/Time mode, press and hold **B** and **C** together for more than 2 seconds. The display will turn off.

The clock will work normally and other functions will be reset.

To turn the display back on press **any** button for more than 1 second.

Step and Alarm Mode

See above on how to navigate to this screen.

Press **D** to toggle alarm on/off

Set Alarm: Press and hold **A** for 2 seconds until digits flash.

Press and hold **B** to cycle through the sections.

Use **C** to decrease digits and **D** increase digits.

Press **A** to save your settings.

Reset step counter: In the step screen, press and hold **C** for 2 seconds to reset.

Set Time and Date:

Go to the calendar screen.

Press and hold **A** until the digits begin to flash.

Press **B** to cycle through the values.
Press **D** to increase the value or **C** to decrease.

Press **A** to exit and save.

Additional functions:

Backlight: Press **A**

Daylight Saving Time: In Calendar/Time mode, press **B** to turn DST on/off. Additional time will be automatically turned on.